

TruSeq DNA PCR-Free Library Prep Protocol Guide

For Research Use Only. Not for use in diagnostic procedures.

Fragment DNA	3
Repair Ends and Select Library Size	5
Adenylate 3' Ends	7
Ligate Adapters	8
Validate Libraries	10
Normalize and Pool Libraries	11
Acronyms	12
Technical Assistance	13



This document and its contents are proprietary to Illumina, Inc. and its affiliates ("Illumina"), and are intended solely for the contractual use of its customer in connection with the use of the product(s) described herein and for no other purpose. This document and its contents shall not be used or distributed for any other purpose and/or otherwise communicated, disclosed, or reproduced in any way whatsoever without the prior written consent of Illumina. Illumina does not convey any license under its patent, trademark, copyright, or common-law rights nor similar rights of any third parties by this document.

The instructions in this document must be strictly and explicitly followed by qualified and properly trained personnel in order to ensure the proper and safe use of the product(s) described herein. All of the contents of this document must be fully read and understood prior to using such product(s).

FAILURE TO COMPLETELY READ AND EXPLICITLY FOLLOW ALL OF THE INSTRUCTIONS CONTAINED HEREIN MAY RESULT IN DAMAGE TO THE PRODUCT(S), INJURY TO PERSONS, INCLUDING TO USERS OR OTHERS, AND DAMAGE TO OTHER PROPERTY.

ILLUMINA DOES NOT ASSUME ANY LIABILITY ARISING OUT OF THE IMPROPER USE OF THE PRODUCT(S) DESCRIBED HEREIN (INCLUDING PARTS THEREOF OR SOFTWARE).

© 2015 Illumina, Inc. All rights reserved.

Illumina, 24sure, BaseSpace, BeadArray, BlueFish, BlueFuse, BlueGnome, cBot, CSPro, CytoChip, DesignStudio, Epicentre, GAllx, Genetic Energy, Genome Analyzer, GenomeStudio, GoldenGate, HiScan, HiSeq, HiSeq X, Infinium, iScan, iSelect, MiSeq, NeoPrep, Nextera, NextBio, NextSeq, Powered by Illumina, SeqMonitor, SureMDA, TruGenome, TruSeq, TruSight, Understand Your Genome, UYG, VeraCode, verifi, VeriSeq, the pumpkin orange color, and the streaming bases design are trademarks of Illumina, Inc. and/or its affiliate(s) in the U.S. and/or other countries. All other names, logos, and other trademarks are the property of their respective owners.

Fragment DNA

Procedure

- 1 Quantify gDNA using a fluorometric-based method.
- 2 Normalize gDNA with RSB to 55 μ l in the DNA plate.
 - 20 ng/ μ l for a 350 bp insert size
 - 40 ng/ μ l for a 550 bp insert size
- 3 Mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 4 Centrifuge as follows.
 - [HS] Centrifuge at $280 \times g$ for 1 minute.
 - [LS] Centrifuge briefly.
- 5 Transfer 52.5 μ l DNA to Covaris tubes.
- 6 Centrifuge at $280 \times g$ for 5 seconds.
- 7 Fragment the DNA using the following Covaris settings.

Table 1 350 bp Insert Settings

Covaris Setting	M220	S220	S2	E210
Duty Factor (%)	20	5	10	
Intensity	—	—	5.0	
Peak/Displayed Power (W)	50	175	23	14
Cycles/Burst	200			
Duration (seconds)	65	50	45	
Mode	—	Frequency sweeping		
Temperature ($^{\circ}$ C)	20	5.5–6		

Table 2 550 bp Insert Settings

Covaris Setting	M220	S220	S2	E210
Duty Factor (%)	20	5	10	
Intensity	—	—	2.0	
Peak/Displayed Power (W)	50	175	9	7
Cycles/Burst	200			
Duration (seconds)	45	25	45	
Mode	—	Frequency sweeping		
Temperature ($^{\circ}$ C)	20	5.5–6		

- 8 Centrifuge at $280 \times g$ for 5 seconds.
- 9 Transfer 50 μ l supernatant to the CSP plate.
- 10 Add 80 μ l SPB, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 11 Incubate at room temperature for 5 minutes.
- 12 [HS] Centrifuge at $280 \times g$ for 1 minute.
- 13 Place on a magnetic stand and wait until the liquid is clear (~8 minutes).

- 14 Remove and discard all supernatant.
- 15 Wash 2 times with 200 μ l 80% EtOH.
- 16 Use a 20 μ l pipette to remove residual EtOH.
- 17 Air-dry on the magnetic stand for 5 minutes.
- 18 Add 52.5 μ l RSB.
- 19 Remove from the magnetic stand, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 20 Incubate at room temperature for 2 minutes.
- 21 [HS] Centrifuge at $280 \times g$ for 1 minute.
- 22 Place on a magnetic stand and wait until the liquid is clear (2–5 minutes).
- 23 Transfer 50 μ l supernatant to the IMP plate.

Repair Ends and Select Library Size

Preparation

- 1 [HS] Preheat the microheating system to 30°C.
- 2 [LS] Save the following ERP program on the thermal cycler:
 - Choose the preheat lid option and set to 100°C
 - 30°C for 30 minutes
 - Hold at 4°C

Procedure

- 1 Add 10 µl CTE.
- 2 Add 40 µl ERP2 or ERP3, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 3 [HS] Centrifuge at 280 × g for 1 minute.
- 4 Incubate as follows.
 - [HS] Place on the 30°C microheating system with the lid closed for 30 minutes, and then place on ice.
 - [LS] Place on the thermal cycler and run the ERP program.
- 5 Dilute SPB with PCR grade water to 160 µl per 100 µl of end-repaired sample.
 - When processing ≤ 6 samples, use a new 1.7 ml microcentrifuge tube.
 - When processing > 6 samples, use a new 15 ml conical tube.

Determine the volumes using the following formulas, which include 15% excess for multiple samples.

Table 3 Diluted SPB for a 350 bp Insert Size

	Formula	Example Amount per 12 samples	Your Calculation
SPB	# of samples X 109.25 µl	1311 µl	
PCR grade water	# of samples X 74.75 µl	897 µl	

Table 4 Diluted SPB for a 550 bp Insert Size

	Formula	Example Amount per 12 samples	Your Calculation
SPB	# of samples X 92 µl	1104 µl	
PCR grade water	# of samples X 92 µl	1104 µl	

- 6 Vortex diluted SPB until well-dispersed.
- 7 Add 160 µl diluted SPB, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 8 Incubate at room temperature for 5 minutes.
- 9 [HS] Centrifuge at 280 × g for 1 minute.
- 10 Place on a magnetic stand and wait until the liquid is clear (~5 minutes).
- 11 Transfer 250 µl supernatant to the CEP plate.

- 12 Add 30 μ l undiluted SPB, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 13 Incubate at room temperature for 5 minutes.
- 14 [HS] Centrifuge at $280 \times g$ for 1 minute.
- 15 Place on a magnetic stand and wait until the liquid is clear (~5 minutes).
- 16 Remove and discard all supernatant.
- 17 Wash 2 times with 200 μ l 80% EtOH.
- 18 Use a 20 μ l pipette to remove residual EtOH.
- 19 Air-dry on the magnetic stand for 5 minutes.
- 20 Add 17.5 μ l RSB.
- 21 Remove from the magnetic stand, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 22 Incubate at room temperature for 2 minutes.
- 23 [HS] Centrifuge at $280 \times g$ for 1 minute.
- 24 Place on a magnetic stand and wait until the liquid is clear (~5 minutes).
- 25 Transfer 15 μ l supernatant to the ALP plate.

SAFE STOPPING POINT

If you are stopping, seal the plate and store at -25°C to -15°C for up to 7 days.

Adenylylate 3' Ends

Preparation

- 1 [HS] Preheat 2 microheating systems, the first to 37°C and the second to 70°C.
- 2 [LS] Save the following ATAIL70 program on the thermal cycler:
 - Choose the preheat lid option and set to 100°C
 - 37°C for 30 minutes
 - 70°C for 5 minutes
 - 4°C for 5 minutes
 - Hold at 4°C

Procedure

- 1 Add 2.5 µl CTA.
- 2 Add 12.5 µl ATL or ATL2, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 3 Incubate as follows.
 - [HS]
 - a Place on the 37°C microheating system with the lid closed for 30 minutes.
 - b Move to the 70°C microheating system with the lid closed for 5 minutes.
 - c Place on ice for 5 minutes.
 - [LS]
 - a Place on the thermal cycler and run the ATAIL70 program.

Ligate Adapters

Preparation

- 1 [HS] Preheat a microheating system to 30°C.
- 2 [LS] Save the following LIG program on the thermal cycler:
 - Choose the preheat lid option and set to 100°C
 - 30°C for 10 minutes
 - Hold at 4°C

Procedure

- 1 Add the following reagents in the order listed, and then mix thoroughly as follows.

Reagent	Volume (μl)
CTL	2.5
LIG2	2.5
DNA adapters	2.5

- [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 2 Centrifuge at 280 × g for 1 minute.
 - 3 Incubate as follows.
 - [HS] Place on the 30°C microheating system with the lid closed for 10 minutes, and then place on ice.
 - [LS] Place on the thermal cycler and run the LIG program.
 - 4 Add 5 μl STL, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
 - 5 [HS] Centrifuge at 280 × g for 1 minute.
 - 6 Perform steps 6a through 6m using the **Round 1** volumes.
 - a Add SPB, and then mix thoroughly as follows.

	Round 1	Round 2
SPB	42.5 μl	50 μl

- [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- b Incubate at room temperature for 5 minutes.
 - c [HS] Centrifuge at 280 × g for 1 minute.
 - d Place on a magnetic stand and wait until the liquid is clear (2–5 minutes).
 - e Remove and discard all supernatant.
 - f Wash 2 times with 200 μl 80% EtOH.
 - g Use a 20 μl pipette to remove residual EtOH.
 - h Air-dry on the magnetic stand for 5 minutes.
 - i Add RSB.

	Round 1	Round 2
RSB	52.5 μl	22.5 μl

- j Remove from the magnetic stand, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
 - k Incubate at room temperature for 2 minutes.
 - l [HS] Centrifuge at $280 \times g$ for 1 minute.
 - m Place on a magnetic stand and wait until the liquid is clear (2–5 minutes).
- 7 Transfer 50 μ l supernatant to the CAP plate.
 - 8 Repeat steps 6a through 6m with the new plate using the **Round 2** volumes.
 - 9 Transfer 20 μ l supernatant to the TSP1 plate.

SAFE STOPPING POINT

If you are stopping, seal the plate and store at -25°C to -15°C for up to 7 days.

Validate Libraries

- 1 Quantify the libraries using qPCR, with the following modifications.
 - ▶ Use at least 2 μ l of the original library stock.
 - ▶ Perform 2 additional dilutions.

The concentration of each library is calculated as indicated in Table 5–Table 6.

Table 5 350 bp Library Concentration Calculation

Dilution Factor	Calculated by qPCR instrument (pM)*		Average diluted library (pM)	Size adjusted diluted library (pM)	Undiluted library (pM)*	Undiluted library (pM)
	A1	A2				
1:10,000	A1	A2	A = (A1 + A2)/2	W1 = A x (452/470)	C1 = W1 x 10,000	(C1 + C2)/2
1:20,000	B1	B2	B = (B1 + B2)/2	W2 = B x (452/470)	C2 = W2 x 20,000	

Table 6 550 bp Library Concentration Calculation

Dilution Factor	Calculated by qPCR instrument (pM)*		Average diluted library (pM)	Size adjusted diluted library (pM)	Undiluted library (pM)*	Undiluted library (pM)
	C1	C2				
1:10,000	C1	C2	C = (C1 + C2)/2	W3 = C x (452/670)	C3 = W3 x 10,000	(C3 + C4)/2
1:20,000	D1	D2	D = (D1 + D2)/2	W4 = D x (452/670)	C4 = W4 x 20,000	

*Duplicate data points

- ▶ Determine the concentration of the diluted library.
- ▶ Perform a size adjustment calculation.
 - For 350 bp libraries, use 470 bp for the average fragment length
 - For 450 bp libraries, use TBD bp for the average fragment length
 - For 550 bp libraries, use 670 bp for the average fragment length
- ▶ Calculate the concentration of the undiluted library.
- ▶ If a replicate is an outlier, it can be omitted from the calculation. If multiple replicates are outliers, repeat the assay.

Quality Control

Verify fragment size by checking the library size distribution.

- 1 Dilute the DNA library 1:5 with water.
- 2 Run 1 μ l diluted DNA library on a High Sensitivity DNA chip.

Normalize and Pool Libraries

Procedure

- 1 Transfer 5 μ l library to the DCT plate.
- 2 Normalize with Tris-HCl 10 mM, pH 8.5 with 0.1% Tween 20 to 2 nM, and then mix thoroughly as follows.
 - [HS] Shake at 1000 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 3 [HS] Centrifuge at $280 \times g$ for 1 minute.
- 4 If pooling 2–24 samples, transfer 5 μ l of each normalized library to a single well of the PDP plate.
- 5 If pooling 25–96 samples, do the following.
 - a Transfer 5 μ l of each column of normalized library to column 1 of the PDP plate, and then mix thoroughly as follows.
 - [HS] Shake at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
 - b [HS] Centrifuge at $280 \times g$ for 1 minute.
 - c Transfer the contents of each well of column 1 to well A2.
- 6 Mix thoroughly as follows.
 - [HS] Shake plate at 1800 rpm for 2 minutes.
 - [LS] Pipette up and down.
- 7 [HS] Centrifuge at $280 \times g$ for 1 minute.
- 8 Proceed to cluster generation.

SAFE STOPPING POINT

If you are stopping, seal the plate and store at -25°C to -15°C .

Acronyms

Acronym	Definition
ALP	Adapter Ligation Plate
ATL	A-Tailing Mix
CAP	Clean Up ALP Plate
CEP	Clean Up End Repair Plate
CSP	Clean Up Sheared DNA Plate
CTA	A-Tailing Control
CTE	End Repair Control
CTL	Ligation Control
DAP	DNA Adapter Plate
DCT	Diluted Cluster Template Plate
DNA	Customer Sample DNA Plate
ERP	End Repair Mix
IMP	Insert Modification Plate
LIG	Ligation Mix
PDP	Pooled Dilution Plate
RSB	Resuspension Buffer
SPB	Sample Purification Beads
STL	Stop Ligation Buffer
TSP1	Target Sample Plate 1

Technical Assistance

For technical assistance, contact Illumina Technical Support.

Table 7 Illumina General Contact Information

Website	www.illumina.com
Email	techsupport@illumina.com

Table 8 Illumina Customer Support Telephone Numbers

Region	Contact Number	Region	Contact Number
North America	1.800.809.4566	Italy	800.874909
Australia	1.800.775.688	Netherlands	0800.0223859
Austria	0800.296575	New Zealand	0800.451.650
Belgium	0800.81102	Norway	800.16836
Denmark	80882346	Spain	900.812168
Finland	0800.918363	Sweden	020790181
France	0800.911850	Switzerland	0800.563118
Germany	0800.180.8994	United Kingdom	0800.917.0041
Ireland	1.800.812949	Other countries	+44.1799.534000

Safety Data Sheets

Safety data sheets (SDSs) are available on the Illumina website at support.illumina.com/sds.html.

Product Documentation

Product documentation in PDF is available for download from the Illumina website. Go to support.illumina.com, select a product, then select **Documentation & Literature**.



Part # 15075699 Rev. A



Illumina
San Diego, California 92122 U.S.A.
+1.800.809.ILMN (4566)
+1.858.202.4566 (outside North America)
techsupport@illumina.com
www.illumina.com